

## Panaboard Software Revision History (5/7/2008)

for UB-5325 / 5825 / 7325 /5315 / 5815 / 5310 / 5320 / 5820 / 7320 /  
528P / 628P / 728P / 5328 / 5828 / 5318 / 518B / 618B / 718B

**(c) 2003-2010 Panasonic System Networks Co., Ltd. All Rights Reserved.**

### TWAIN Driver

Ver.	Changing issue(s) / Fixing problem(s)	Note
1.00	1. First Release	
2.00	1. TWAIN Driver name is changed into "Panaboard UB5-7 USB TWAIN Driver" from "Panaboard UB-5 USB TWAIN Driver". 2. Button-Operations in Operation Panel are enabled by Short-cut key. 3. TWAIN Driver judges connection model automatically, displays Operating panel according to the model.	
2.01	1. (Fix) TWAIN Driver cannot close after scanning in KODAK Imaging software in case of connecting by PRICOM (Wireless USB Print Server). It occurs with Windows2000.	
3.00	1. Adding Help button and changing help to HTML Help format.	Version for Windows Vista 32bit

### Printer Driver (Windows98/Me)

Ver.	Changing issue(s) / Fixing problem(s)	Note
1.00	1. First Release	
1.20	1. "Panaboard-UB7 USB Printer (LT)" and "Panaboard-UB7 USB Printer (A4)" are added for Panaboard 4-screen model (UB-7325/7320) for Windows98/Me.	

### Printer Driver (Windows2000/XP/Vista)

Ver.	Changing issue(s) / Fixing problem(s)	Note
1.00	1. First Release	
2.00	1. "Panaboard-UB7 USB Printer (LT)" and "Panaboard-UB7 USB Printer (A4)" are added for Panaboard 4-screen model (UB-7325/7320) for Windows2000/XP.	
3.00	1. Changing for Windows Vista 32bit.	Version for Windows Vista 32bit

### Board Image Capture

Ver.	Changing issue(s) / Fixing problem(s)	Note
3.2.0.1	1. First Release	

### Software Installer

Ver.	Changing issue(s) / Fixing problem(s)	Note
1.00	1. First Release	
2.00	1. Changing for Windows Vista 32bit.	Version for Windows Vista 32bit
2.14	1. Adding Board Image Capture.	

### Notes of Software Installation on Windows Vista 32bit

1. If the User Account Control window is displayed, select [Allow].
  2. If the Windows Security window is displayed, select [Install this driver software anyway].
- When connecting the USB cable to your computer, the wizard window is not displayed in Windows Vista.

\* Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.