


◆ Hole Removal

<Function>


This function removes the punch hole marks from the scanned image.



【Demo Document】



Hole is removed.

<ICP Setting Procedures>



1. Click "Scan"  at the left side. The "New Document – Scan" dialog box is displayed.
2. Click "Scan Setting" .
3. Select "24 bit color" in "Image Type".
4. Select "Common" tab.
5. Check "Hole Removal" in Image Filter
6. Click "OK"
7. Click the "Start" button to begin scanning.

<Notes>

- Set the reference plate and flatbed sheet to black when using the Hole Removal function.
- Punched holes are not removed unless they are neatly round.
- The Hole Removal function may not work properly when the punch holes are made on top of texts or pictures.
- If holes are made in an area of the scanned document containing a straight line, the artifacts of the hole are removed and the line is reconstructed.
- If a line is close to the edge of a hole or intersects with text or pictures, the artifacts of the hole may not be detected or removed.
- Depending on the images to be scanned, the Hole Removal function may not work properly