

RS232C/LAN command list
MODEL : 4K LCD Display TH-86/75/65/55/50/43EQ1

2022/4/1
Panasonic Connect Co.,Ltd.

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby		
Basic Control	Power ON	PON	Avail	-	-	-	-	Power ON
	Power OFF	POF	-	-	-	-	-	Power OFF
	Power Status	-	-	QPW	QPW:*	Avail	0 / 1	0 : Standby (Off) 1 : Power ON (On)
	Input Change	IMS (:***)	Not avail	QMI	QMI:***	Avail	Control:(Toggle) HM1/HM2/DV1/PC1/VD1/UD1/MV1 Inquiry: HM1/HM2/DV1/PC1/VD1/UD1/MV1	HM1 : HDMI1 HM2 : HDMI2 DV1 : DVI-D PC1 : PC(*PC[YPBPR]) VD1 : VIDEO UD1 : USB MV1 : MEMORY VIEWER
	Audio Volume	AVL:***	Not avail	-	-	-	000 - 100	Volume value
	Volume Up	AUU	Not avail	-	-	-	-	Volume Up
	Volume Down	AUD	Not avail	-	-	-	-	Volume Down
	Current Audio Volume	-	-	QAV	QAV:***	Avail	000 - 100	Volume value
	Audio Mute	AMT (:*)	Not avail	QAM	QAM: *	Avail	Control:(Toggle) 0 / 1	Toggle (Audio mute Off) / (Audio mute On)
	Video Mute	VMT (:*)	Not avail	QVM	QVM: *	Avail	Control:(Toggle) 0 / 1	Toggle (Video mute Off) / (Video mute On)
	Aspect Change	DAM:****	Not avail	QAS	QAS:****	Not avail	FULL / NORM / NATV / HFIT / VFIT / ZOOM / ZOM2	FULL / NORMAL / REAL / H FIT / V FIT / ZOOM1 / ZOOM2
	Picture Adjustment	Picture Mode	VPC:MEN***	Not avail	QPC:MEN	QPC:MEN***	Not avail	VIV / NAT / STD / SUV / GRH / DCM
Backlight		VPC:BLT***	Not avail	QPC:BLT	QPC:BLT***	Avail	000 ~ 100 DEF	0 ~ 100 DEF:SET SHIPPING VALUE Available when Power save is Off.
Picture Contrast		VPC:PIC***	Not avail	QPC:PIC	QPC:PIC***	Avail	000 ~ 100 DEF	0 ~ 100 DEF:SET SHIPPING VALUE
Black Level Brightness		VPC:BLK***	Not avail	QPC:BLK	QPC:BLK***	Avail	000 ~ 100 DEF	0 ~ 100 DEF:SET SHIPPING VALUE
Color		VPC:COL***	Not avail	QPC:COL	QPC:COL***	Avail	000 ~ 100 DEF	0 ~ 100 DEF:SET SHIPPING VALUE
Tint		VPC:TIN***	Not avail	QPC:TIN	QPC:TIN***	Not avail	000 ~ 100 DEF	0 ~ 100 DEF:SET SHIPPING VALUE
Sharpness		VPC:SHP***	Not avail	QPC:SHP	QPC:SHP***	Avail	000 ~ 100 DEF	0 ~ 100 DEF:SET SHIPPING VALUE
Enhance level		VPC:SHE*	Not avail	QPC:SHE	QPC:SHE*	Not avail	1 / 2	1: low 2: high
Gamma		VWB:GMM**	Not avail	QWB:GMM	QWB:GMM**	Not avail	20 / 22 / 24 / 26	2.0 / 2.2 / 2.4 / 2.6
Color Temperature		VPC:TMP***	Not avail	QPC:TMP	QPC:TMP***	Not avail	032 / 040 / 050 / 065 / 075 / 093 / 107 / NTV / U01 / U02	3200K ~ 10700K / NaTiVe / USER1 / USER2
Red Gain		VWB:RGN****	Not avail	QWB:RGN	QWB:RGN****	Not avail	0000 ~ 0255	0 ~ 255 Available when Color Temperature is USER1 or USER2.
Green Gain		VWB:GGN****	Not avail	QWB:GGN	QWB:GGN****	Not avail	0000 ~ 0255	0 ~ 255 Available when Color Temperature is USER1 or USER2.
Blue Gain		VWB:BGN****	Not avail	QWB:BGN	QWB:BGN****	Not avail	0000 ~ 0255	0 ~ 255 Available when Color Temperature is USER1 or USER2.
Red Bias	VWB:RBS****	Not avail	QWB:RBS	QWB:RBS****	Not avail	-127 ~ 0000 ~ 0128	-127 ~ 128 Available when Color Temperature is USER1 or USER2.	

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation		
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby				
P i c t u r e	Picture Adjustment	Green Bias	VWB:GBS****	Not avail	QWB:GBS	QWB:GBS****	Not avail	-127 ~ 0000 ~ 0128	-127 ~ 128 Available when Color Temperature is USER1 or USER2.	
		Blue Bias	VWB:BBS****	Not avail	QWB:BBS	QWB:BBS****	Not avail	-127 ~ 0000 ~ 0128	-127 ~ 128 Available when Color Temperature is USER1 or USER2.	
		6-segment color management	VWB:CMF*	Not avail	QWB:CMF	QWB:CMF*	Not avail	0 / 1	0 : off / 1 : on	
		6-segment color management select color	VWB:CML* **** **** ****	Not avail	QWB:CML*	QWB:CML* **** **** ****	Not avail	R / Y / G / C / B / M -511 ~ 0000 ~ 0511 -127 ~ 0000 ~ 0127 -127 ~ 0000 ~ 0127	Red / Yellow / Green / Cyan / Blue / Magenta TINT : -511 ~ 511 SATURATION : -127 ~ 127 VALUE : -127 ~ 127 Available when 6-segment color management is on	
		6-segment color management reset	VWB:CMR	Not avail	-	-	Not avail	-	Available when 6-segment color management is on	
		Dynamic Contrast	VPC:DCO**	Not avail	QPC:DCO	QPC:DCO**	Not avail	00 ~ 10	0 ~ 10	
		Color Enhancement	VPC:PAJ*	Not avail	QPC:PAJ	QPC:PAJ*	Not avail	0 / 1	OFF / ON	
		Refine enhancer	VPC:SRC*	Not avail	QPC:SRC	QPC:SRC*	Not avail	0 / 1 / 2 / 3	OFF / Low / Mid / High	
		Gradation smoother	VPC:GRS*	Not avail	QPC:GRS	QPC:GRS*	Not avail	0 / 1	0 : off / 1 : on	
	Memory function	Memory delete	VPF:DEL**	Not avail	-	-	-	01 ~ 06	Memory No.1 - Memory No.6	
		Memory load	VPF:LOD**	Not avail	-	-	-	01 ~ 06	Memory No.1 - Memory No.6	
		Memory name change	VPF:NAM** *...*	Not avail	QPF:NAM**	QPF:NAM** *...*	Not avail	01 ~ 06 space ! " # \$ % & ' () * + , - . / 0 1 2 3 4 5 6 7 8 9 : ; < = > ? @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z [\] ^ _ ` a b c d e f g h i j k l m n o p q r s t u v w x y z { } ~	Memory No.1 - Memory No.6 Memory name(Max 20 Parameters)	
		Memory save	VPF:SAV** *...*	Not avail	-	-	-	01 ~ 06 space ! " # \$ % & ' () * + , - . / 0 1 2 3 4 5 6 7 8 9 : ; < = > ? @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z [\] ^ _ ` a b c d e f g h i j k l m n o p q r s t u v w x y z { } ~	Memory No.1 - Memory No.6 Memory name(Max 20 Parameters)	
		Memory state	-	-	QPF:STA	QPF:STA*****	Not avail	- / 0 (Memory No.1 - No.06)	Unused / Use	
		Output Select	AAC:OUT***	Not avail	QAC:OUT	QAC:OUT***	Not avail	SPO / LNO	SPEAKERS / AUDIO OUT	
	S o u n d	Sound Adjustment	Balance	AAC:BAL***	Not avail	QAC:BAL	QAC:BAL***	Not avail	-20 ~ 000 ~ +20(020)	-20 ~ 20 Available when Output Select is SPEAKERS.
			Sound Mode	AAC:MEN***	Not avail	QAC:MEN	QAC:MEN***	Not avail	STD(AUT) / DYN / CLR	STANDARD / DYNAMIC / CLEAR Available when Output Select is SPEAKERS.
			Bass	AAC:BAS***	Not avail	QAC:BAS	QAC:BAS***	Not avail	-20 ~ 000 ~ +20(020)	-20 ~ 20 Available when Output Select is SPEAKERS.
			Treble	AAC:TRE***	Not avail	QAC:TRE	QAC:TRE***	Not avail	-20 ~ 000 ~ +20(020)	-20 ~ 20 Available when Output Select is SPEAKERS.
Surround			AAC:SUR***	Not avail	QAC:SUR	QAC:SUR***	Not avail	MON / OFF	ON / OFF Available when Output Select is SPEAKERS.	
Auto Volume * Main software version 2.2000 or later			AAC:ATV***	Not avail	QAC:ATV	QAC:ATV***	Not avail	OFF / LOW / MID / HIG	Off / Low / Middle / High	
Installation * Main software version 2.2000 or later			AAC:IST***	Not avail	QAC:IST	QAC:IST***	Not avail	STD / WMT	Stand / Wall mounted	
P o s i t i o n			Position/Size Adjustment	Horizontal Position	DGE:HPO****	Not avail	QGE:HPO	QGE:HPO****	Not avail	-100 ~ 0000 ~ +100(0100)
	Horizontal Size	DGE:HSZ****		Not avail	QGE:HSZ	QGE:HSZ****	Not avail	-100 ~ 0000 ~ +100(0100)	H-Size : -100 - 0000 - +100(0100)	
	Vertical Position	DGE:VPO****		Not avail	QGE:VPO	QGE:VPO****	Not avail	-100 ~ 0000 ~ +100(0100)	V-Pos : -100 - 0000 - +100(0100)	
	Vertical Size	DGE:VSZ****		Not avail	QGE:VSZ	QGE:VSZ****	Not avail	-100 ~ 0000 ~ +100(0100)	V-Size : -100 - 0000 - +100(0100)	
	Clock Phase	DGE:CLK***		Not avail	QGE:CLK	QGE:CLK***	Not avail	00 ~ 30	0 ~ 30	
	Dot Clock	DGE:DCL***		Not avail	QGE:DCL	QGE:DCL***	Not avail	-5 ~ 00 ~ +5(05)	-5 ~ 5	
	Overscan	DGE:OVS*		Not avail	QGE:OVS	QGE:OVS*	Not avail	0 / 1	OFF / ON	
	Pos./Size Lump Setting	DGE:PSZ**** **** **** ****		Not avail	QGE:PSZ	QGE:PSZ**** **** **** ****	Not avail	-100 ~ 0000 ~ +100(0100), -100 ~ 0000 ~ +100(0100), -100 ~ 0000 ~ +100(0100), -100 ~ 0000 ~ +100(0100)	H-Pos : -100 - 0000 - +100(0100) H-Size : -100 - 0000 - +100(0100) V-Pos : -100 - 0000 - +100(0100) V-Size : -100 - 0000 - +100(0100)	

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation	
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby			
Position/Size Adjustment	Auto Setup	DGE:ASU*	Not avail	QGE:ASU	QGE:ASU	Not avail	Control: 1 Inquiry: OK NG OF NW	Control: 1 : Execution start Inquiry: OK : result OK NG : result NG OF : Un-performing or when not effective NW : adjusting	
	PC auto setting	OSP:PAS*	Not avail	QSP:PAS	QSP:PAS*	Not avail	0 / 1	OFF / ON	
Setup	Input lock	OSP:INL***	Not avail	QSP:INL	QSP:INL***	Not avail	OFF / HM1/HM2/DV1/PC1/VD1/UD1/MV1	OFF / HDMI1 / HDMI2 / DVI-D / PC(*PC[YBPBR]) / VIDEO / USB / MEMORY VIEWER (*PC input mode:PC[YBPBR])	
	Off-timer function	OSP:OFT*	Not avail	QSP:OFT	QSP:OFT*	Not avail	0 / 1	OFF / ON	
	No activity power off	SSU:NAO*	Not avail	QSU:NAO	QSU:NAO*	Not avail	0 / 1	OFF / ON	
	OSD Language	SSU:LNG***	Not avail	QSU:LNG	QSU:LNG***	Not avail	ENG / DEU / FRA / ITL(ITA) / ESP / USA / CHA / JPN / RUS	English (UK) / German / French / Italian / Spanish / English (US) / Chinese/Japanese / Russian	
	Display Orientation	SSU:DOR*	Not avail	QSU:DOR	QSU:DOR*	Not avail	0 / 1	Landscape / Portrait	
	Image rotation	SSU:IMR*	Not avail	QSU:IMR	QSU:IMR*	Not avail	0 / 1	Off / 180 degrees	
	Maximum VOL level	OSP:MVL****	Not avail	QSP:MVL	QSP:MVL****	Not avail	0 / 1, 000 ~ 100	function : OFF / ON, volume : 0~100	
	Button lock	OSP:BTL***	Not avail	QSP:BTL	QSP:BTL***	Not avail	OFF / MEN / ALL	OFF / MENU&ENTER / ON	
	Controller User level	OSP:RCM*	Not avail	QSP:RCM	QSP:RCM*	Not avail	0 / 1 / 2 / 3	OFF / User1 / User2 / User3	
	PC input mode	SSU:PCM*	Not avail	QSU:PCM	QSU:PCM*	Not avail	0 / 1	PC / PC[YBPBR]	
	3D Y/C Filter	SSG:YCS*	Not avail	QSG:YCS	QSG:YCS*	Not avail	0 / 1	OFF / ON	
	Color System	SSG:COS***	Not avail	QSG:COS	QSG:COS***	Not avail	NTS / PAL / SCM / 4NT / MPA / NPA / AUT	NTSC / PAL / SECAM / NTSC4.43 / PAL-M / PAL-N / AUTO	
	Cinema Reality 3:2 Pull Down	SSG:DCR*	Not avail	QSG:DCR	QSG:DCR*	Not avail	0 / 1	OFF / ON	
	XGA Mode	SSG:XGA*	Not avail	QSG:XGA	QSG:XGA*	Not avail	1 / 2 / 3 / 4	1:1024x768 2:1280x768 3:1366x768 4:Auto	
	Noise Reduction	SSG:NRS***	Not avail	QSG:NRS	QSG:NRS***	Not avail	OFF / AUT / LOW / MID / HIG	OFF / Auto / Low / Middle / High	
	MPEG Noise Reduction	SSG:MNR***	Not avail	QSG:MNR	QSG:MNR***	Not avail	OFF / LOW / MID / HIG	OFF / Low / Middle / High	
	Signal Range	SSG:HRC***	Not avail	QSG:HRC	QSG:HRC***	Not avail	VID / FUL / AUT	(HDMI input) Video / FULL / Auto (DVI-D input) Video / FULL / Auto (Other input) not avail	
	YUV/RGB-IN Select	SSU:DYR***	Not avail	QSU:DYR	QSU:DYR***	Not avail	YUV / RGB	YUV Signal / RGB Signal Available when HDMI1/HDMI2/DVI-D is selected.	
	Input Level	VWB:ILV***	Not avail	QWB:ILV	QWB:ILV***	Not avail	-16 ~ 000 ~ +16(016)	-16 ~ 16	
	FRAME CREATION	VPC:FRC*	Not avail	QPC:FRC	QPC:FRC*	Not avail	0 / 1	(86/75 inch only) OFF / ON	
	Dynamic backlight control	SSG:DBC*	Not avail	QSG:DBC	QSG:DBC*	Not avail	0 / 1	OFF / ON	
	EDID select	SSG:EID*	Not avail	QSG:EID	QSG:EID*	Not avail	0 / 1 / 2	4K/60p / 4K/60p / 2K	
	Power on settings	Initial input	OSP:IIN***	Not avail	QSP:IIN	QSP:IIN***	Not avail	OFF / HM1/HM2/DV1/PC1/VD1/UD1/MV1	OFF / HDMI1 / HDMI2 / DVI-D / PC(*PC[YBPBR]) / VIDEO / USB / MEMORY VIEWER (*PC input mode:PC[YBPBR])
		Initial Startup	OSP:ISU***	Not avail	QSP:ISU	QSP:ISU***	Not avail	LST PON STB	LST : Last memory(return to a front state) PON : ON STB : STANDBY
		Initial VOL level	OSP:IVL****	Not avail	QSP:IVL	QSP:IVL****	Not avail	0 / 1, 000 ~ 100	function : OFF / ON, volume : 0~100
		Power ON Screen Delay	OSP:POD**	Not avail	QSP:POD	QSP:POD**	Not avail	AT / 00 ~ 30	AT : Auto 0~30 : 0~30 seconds
		Information(No activity power off)	OSP:NAP*	Not avail	QSP:NAP	QSP:NAP*	Not avail	0 / 1	OFF / ON
Information(Power management)		OSP:PMM*	Not avail	QSP:PMM	QSP:PMM*	Not avail	0 / 1	OFF / ON	

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation	
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby			
Set up	Power on settings	Quick start * Japanese model only & Main Ver 2.2000 or later & Sub Ver 02.00 or later.	SSU:QST*	Not avail	QSU:QST	QSU:QST	Not avail	0 / 1	OFF / ON
	Input search	Input search	ISH:FNC***	Not avail	QSH:FNC	QSH:FNC***	Not avail	OFF / ALL / PRI / IDC	OFF / ALL inputs / Custom / Input detection
		1st search input	ISH:PRI***	Not avail	QSH:PRI	QSH:PRI***	Not avail	NON / HM1 / HM2 / DV1 / PC1 / VD1 / UD1	(none) / HDMI1 / HDMI2 / DVI-D / PC(*PC[YBPBR]) / VIDEO / USB (*PC input mode:PC[YBPBR])
		2nd search input	ISH:SCI***	Not avail	QSH:SCI	QSH:SCI***	Not avail	NON / HM1 / HM2 / DV1 / PC1 / VD1 / UD1	(none) / HDMI1 / HDMI2 / DVI-D / PC(*PC[YBPBR]) / VIDEO / USB (*PC input mode:PC[YBPBR])
		Detect digital input	ISH:DIN*** +	Not avail	QSH:DIN***	QSH:DIN***+	Not avail	***:HM1 / HM2 / DV1 / PC1 +:0 / 1	HDMI1 / HDMI2 / DVI-D / PC / OFF / ON
		Changing delay	ISH:CGD**	Not avail	QSH:CGD	QSH:CGD**	Not avail	00 / 01 / 02 / 03 / 04 / 05 / 06 / 07 / 08 / 09 / 10	00 : OFF 01~10 : changing time(sec)
	Failover / Failback	Input Change Mode Off	SBI:OFF (NON NON *)	Not avail	QBI	QBI:OFF NON NON *	Not avail	0	0: Disable (Auto switch back mode)
		Input Change Mode Quick	SBI:QIC (*** *** *)	Not avail	QBI	QBI:QIC *** *** *	Not avail	NON / HM1 / HM2 NON / HM1 / HM2 0 / 1	Primary backup input : (None) / HDMI1 / HDMI2 Secondary backup input : (None) / HDMI1 / HDMI2 Auto switch back mode : 0: Disable / 1 : Enable
		Input Change Mode Normal	SBI:NOR (*** *** *)	Not avail	QBI	QBI:NOR *** *** *	Not avail	NON/HM1/HM2/DV1/PC1/UD1 NON/HM1/HM2/DV1/PC1/UD1 0 / 1	Primary backup input : (None) / HDMI1 / HDMI2 / DVI-D / PC / USB Secondary backup input : (None) / HDMI1 / HDMI2 / DVI-D / PC / USB Auto switch back mode : 0: Disable / 1 : Enable
		Changing mode	SBI:CHM*	Not avail	QBI:CHM	QBI:CHM*	Not avail	2 / 1	High speed / Normal speed When [Quick] is selected, [Changing mode] can be adjusted.
		Backup Input Status	-	-	QBI:STS	QBI:STS * *** *	Not avail	0 / 1 HM1/HM2/DV1/PC1/VD1/UD1/MV1 0 / 1 / 2	0: inactive / 1: active (Status) Main Input : HDMI1 / HDMI2 / DVI-D / PC / VIDEO / USB / MEMORY VIEWER 0: Main Input / 1: Primary Backup input / 2: Secondary Backup input (Current Input Status)
		Backup Input Signal Status	-	-	QBI:SIG	QBI:SIG * * *	Not avail	0 / 1 0 / 1 0 / 1	0 : no signal / 1 : not no signal (Main input) 0 : no signal / 1 : not no signal (Primary backup input) 0 : no signal / 1 : not no signal (Secondary backup input) When Input change mode is not Off
		Manual Switch Back	BIP:FSB	Not avail	-	-	Not avail	-	Enable when Input change mode is not Off and Auto switch back mode is Disable.
	Screensaver	Screensaver ON/OFF	OSP:SCR*	Not avail	QSP:SCR	QSP:SCR*	Not avail	0 / 5	0 : stop 5 : operating
		Screensaver Mode	SSC:MOD*	Not avail	QSC:MOD	QSC:MOD*	Not avail	0 / 1 / 2 / 3 / 4	0:OFF 1:Interval 2:Time Designation 3:ON 4:Standby after Screensaver

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation	
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby			
Set up	Screensaver	Interval Screensaver	SSC:INT**** ****	Not avail	QSC:INT	QSC:INT**** ****	Not avail	0000 ~ 2359, 0000 ~ 2359	Periodic time Operating time
		Time Designation Screensaver	SSC:TIM**** ****	Not avail	QSC:TIM	QSC:TIM**** ****	Not avail	0000 ~ 2359, 0000 ~ 2359	Start time Finish time
		Standby after Screensaver	SSC:AOF****	Not avail	QSC:AOF	QSC:AOF****	Not avail	0000 ~ 2359	Time of operation(hour:minute)
		Wobbling	OSP:WOB*	Not avail	QSP:WOB	QSP:WOB*	Not avail	0 / 1	OFF / ON
	Input label	Set Label for Current Input	SSU:ILA***	Not avail	QSU:ILA	QSU:ILA***	Not avail	INP / PCN / DV1 / DV2 / DV3 / BD1 / BD2 / BD3 / CTV / VCR / STB / SKP	reset input name(Except PC) / reset input name(for PC) DVD1 / DVD2 / DVD3 / Blu-ray1 / Blu-ray2 / Blu-ray3 / CATV / VCR / STB / (Skip)
		Set Label for EACH INPUT	SSU:ILA+++***	Not avail	QSU:ILA+++	QSU:ILA +++ ***	Not avail	+++ HM1/HM2/DV1/PC1/VD1 *** INP / PCN / DV1 / DV2 / DV3 / BD1 / BD2 / BD3 / CTV / VCR / STB / SKP	Input HDMI1 / HDMI2 / DVI-D / PC(*PC[YPBPR]) / VIDEO (*PC input mode:PC[YPBPR]) Label reset(input other than PC) / Label reset(PC input) DVD1 / DVD2 / DVD3 / Blu-ray1 / Blu-ray2 / Blu-ray3 / CATV / VCR / STB / Skip
	Audio input select	for Current Input	SAI: A+++	Not avail	QAI	QAI: V*** A+++	Not avail	*** HM1 / HM2 / DV1 / PC1 / VD1 +++ HM1 / HM2 / AI1 / AI2 / NAD	HDMI1 / HDMI2 / DVI-D / PC(*PC[YPBPR]) / VIDEO HDMI1 / HDMI2 / AV IN / AUDIO IN / NO AUDIO (*PC input mode:PC[YPBPR])
		for EACH INPUT	SAI: V*** A+++	Not avail	QAI:V***	QAI: V*** A+++	Not avail	*** HM1 / HM2 / DV1 / PC1 / VD1 +++ HM1 / HM2 / AI1 / AI2 / NAD	HDMI1 / HDMI2 / DVI-D / PC(*PC[YPBPR]) / VIDEO HDMI1 / HDMI2 / AV IN / AUDIO IN / NO AUDIO (*PC input mode:PC[YPBPR])
	Power management settings	Power Management Mode	SSU:ECS*	Not avail	QSU:ECS	QSU:ECS*	Not avail	0 / 1	CUSTOM / ON
		No Signal Power Off	SSU:AOF*	Not avail	QSU:AOF	QSU:AOF*	Not avail	0 / 1	OFF / ON
		HDMI1 Power Management	SSU:D1H*	Not avail	QSU:D1H	QSU:D1H*	Not avail	0 / 1	OFF / ON
		HDMI2 Power Management	SSU:D2H*	Not avail	QSU:D2H	QSU:D2H*	Not avail	0 / 1	OFF / ON
		DVI-D Power Management	SSU:D1V*	Not avail	QSU:D1V	QSU:D1V*	Not avail	0 / 1	OFF / ON
		PC Power Management	SSU:DPM*	Not avail	QSU:DPM	QSU:DPM*	Not avail	0 / 1	OFF / ON
		Power Save	SSU:ECO*	Not avail	QSU:ECO	QSU:ECO*	Not avail	0 / 1	OFF / ON
		Extended standby mode	SSU:ESM*	Not avail	QSU:ESM	QSU:ESM*	Not avail	0 / 1	OFF / ON
	Changing delay	SSU:CGD**	Not avail	QSU:CGD	QSU:CGD**	Not avail	00 / 01 / 02 / 03 / 04 / 05 / 06 / 07 / 08 / 09 / 10	00 : OFF 01~10 : 切替時間(秒)	
	External device link	Device information	SSU:DDP*	Not avail	QSU:DDP	QSU:DDP*	Not avail	0 / 1	OFF / ON
Cisco Systems link		SSU:CIS*	Not avail	QDL:CIS	QDL:CIS*	Not avail	0 / 1	OFF / ON	
HDMI-CEC settings	HDMI-CEC control	SHC:FNC*	Not avail	QHC:FNC	QHC:FNC*	Not avail	0 / 1	Disable / Enable	
	HDMI1 (change device)	SHC:HM1***	Not avail	-	-	-	NXT / PRE	Change to next device / Change to previous device	
	HDMI1 (get device name)	-	-	QHC:HM1	QHC:HM1*...*	Not avail	space ! " # \$ % & ' () * + , - . / 0 1 2 3 4 5 6 7 8 9 ; ; < = > ? @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z [¥] ^ _ ` a b c d e f g h i j k l m n o p q r s t u v w x y z { } -	Device name (Max 23 Parameters)	
	HDMI2 (change device)	SHC:HM2***	Not avail	-	-	-	NXT / PRE	Change to next device / Change to previous device	
	HDMI2 (get device name)	-	-	QHC:HM2	QHC:HM2*...*	Not avail	space ! " # \$ % & ' () * + , - . / 0 1 2 3 4 5 6 7 8 9 ; ; < = > ? @ A B C D E F G H I J K L M N O P Q R S T U V W X Y Z [¥] ^ _ ` a b c d e f g h i j k l m n o p q r s t u v w x y z { } -	Device name (Max 23 Parameters)	
	MENU code	SHC:MNC*	Not avail	QHC:MNC	QHC:MNC*	Not avail	1 / 2 / 3 / 4 / 5 / 6	1 / 2 / 3 / 4 / 5 / 6	
Image settings Startup image settings	Display → Device	SHC:PTS***	Not avail	QHC:PTS	QHC:PTS***	Not avail	OFF / POF / PWR	"Disable" / "Power off" / "Power on / off"	
	Device → Display	SHC:STP***	Not avail	QHC:STP	QHC:STP***	Not avail	OFF / PON / PWR	"Disable" / "Power on" / "Power on / off"	
	Display setting	SCI:SIM*	Not avail	QCI:SIM	QCI:SIM*	Not avail	0 / 1	OFF / ON	
	Image select	SCI:SCG*	Not avail	QCI:SCG	QCI:SCG*	Not avail	0 / 1	0 : Default image 1 : User image	

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation	
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby			
Set up	Image settings No signal image settings	Display setting	SCI:NIM*	Not avail	QCI:NIM	QCI:NIM*	Not avail	0 / 1	OFF / ON
		Image select	SCI:NCG*	Not avail	QCI:NCG	QCI:NCG*	Not avail	0 / 1	0 : Default image 1 : User image
	Multi display settings	Multi Display ON/OFF	MDC:*	Not avail	-	-	-	0 / 1	OFF / ON
		Multi Display Setup Detail	MDC:EXP* ** ** *** *** ***	Not avail	QDC:EXP	QDC:EXP* ** ** *** *** ***	Not avail	0 / 1, 01 ~ 05, 01 ~ 05, 000 ~ 100, 000 ~ 100, 001 ~ 100	OFF / ON, Horizontal scale 1~5, Vertical scale 1~5, Bezel H adjustment 0~100, Bezel V adjustment 0~100, Location (A1~E5)
	Portrait settings	Portrait display	DPR:*	Not avail	QPR	QPR:*	Not avail	0 / 1	OFF / ON
		Inquiry about Portrait display setup	-	-	QPR:DET	QPR:DET* **	Not avail	0 / 1, 01 / 03 / L3	OFF / ON, Portrait 1 screen / Portrait 3 screens / Landscape 3 screens
		Portrait display setup (Instration method: Portrait 1 screen)	DPR:D01*	Not avail	QPR:D01	QPR:D01*	Not avail	0 / 1	OFF / ON
		Portrait display setup (Instration method: Portrait 3 screens)	DPR:D03* * *** **	Not avail	QPR:D03	QPR:D03* * *** **	Not avail	0 / 1, 1 / 2 / 3, 000 ~ 100, 01 ~ 03	OFF / ON, Display format 1=16:9 V fit / 2=16:9 H fit / 3=Full Bezel adjustment 0~100, Location 01=Left / 02=Centre / 03=Right
	Video conference mode settings	HDMI1	SSU:VCMHM1*	Not avail	QSU:VCMHM1	QSU:VCMHM1*	Not avail	0 / 1	OFF / ON
		HDMI2	SSU:VCMHM2*	Not avail	QSU:VCMHM2	QSU:VCMHM2*	Not avail	0 / 1	OFF / ON
		DVI-D	SSU:VCMDV1*	Not avail	QSU:VCMDV1	QSU:VCMDV1*	Not avail	0 / 1	OFF / ON
	Set up timer		TIM:PRG** * *** *** **** ***	Not avail	QIM:PRG**	QIM:PRG** * *** *** **** ***	Not avail	01 ~ 20, 0 / 1, SUN / MON / TUE / WED / THU / FRI / SAT / EVD / WDA / WEN / CUS, PON / POF, 0000 ~ 2359, HM1/HM2/DV1/PC1/VD1/UD1/MV1	Program number : 1~20, Function : OFF / ON, (*Inquiry Command reply, A lower parameter is not given when the upper setup is "OFF.") a day of the week : Sunday / Monday / Tuesday / Wednesday / Thursday / Friday / Saturday / Everyday / Weekday / Weekend / Custom (*Custom can't be set with Control Command. However, after setting, the day on the menu is "Custom".) (*The day of the inquiry response is "Custom" only if it doesn't apply to any of Monday through Weekend.) Action type : PON / POF, Time : hour, minute, Start-up input : HDMI1 / HDMI2 / DVI-D / PC(*PC[YBPBR]) / VIDEO / USB / MEMORY VIEWER (*PC input mode:PC[YBPBR])

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation	
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby			
Set up	Network settings	Crestron Connected™	SSU:CRV*	Not avail	QSU:CRV	QSU:CRV*	Not avail	0 / 1	OFF / ON
		USB memory network settings	SSU:UNS*	Not avail	QSU:UNS	QSU:UNS*	Not avail	0 / 1	Prohibit / Permit
		LAN Control Protocol	OSP:LPN***	Not avail	QSP:LPN	QSP:LPN***	Not avail	LP1 / LP2	Protocol1 / Protocol2
		Reset	SSU:LRT	Not avail	-	-	-	-	
	USB media player settings	USB media player	SUS:UMP*	Not avail	QUS:UMP	QUS:UMP*	Not avail	0 / 1	Disable / Enable
		Schedule play function	SUS:SPF*	Not avail	QUS:SPF	QUS:SPF*	Not avail	0 / 1	Disable / Enable
		Video Playback Mode	SUS:VPB*	Not avail	QUS:VPB	QUS:VPB*	Not avail	0 / 1	Standard / Adjust
		Still picture rotation	SUS:STR*	Not avail	QUS:STR	QUS:STR*	Not avail	0 / 1 / 2	Landscape / Portrait / Exif information
		Resume play	SUS:RSP*	Not avail	QUS:RSP	QUS:RSP*	Not avail	0 / 1	OFF / ON
		Slide show duration	SUS:SSD***	Not avail	QUS:SSD	QUS:SSD***	Not avail	010 ~ 600	10 - 600 seconds (5 second unit)
		Play mode	SUS:SPM*	Not avail	QUS:SPM	QUS:SPM*	Not avail	0 / 1	Individual play / Synchronize play
		get Schedule play mode	-	-	QUS:CMS	QUS:CMS*	Avail	0 / 1	Normal mode / Schedule play mode (standby : Normal standby / Schedule wait standby)
	Memory viewer settings	Memory viewer function	SMS:MVF*	Not avail	QMS:MVF	QMS:MVF*	Not avail	0 / 1	OFF / ON
		View	SMS:VIE***	Not avail	QMS:VIE	QMS:VIE***	Not avail	THU / LIS	Thumbnail / List
		Content select	SMS:CON***	Not avail	QMS:CON	QMS:CON***	Not avail	STL / VID / AUD / ALL / SAV / SAA / VAA	Picture / Video / Audio / All / Picture/Video / Picture/Audio / Video/Audio
		Sort type	SMS:TYP***	Not avail	QMS:TYP	QMS:TYP***	Not avail	DAT / NAM	Date / Name
		Sort order	SMS:ODR***	Not avail	QMS:ODR	QMS:ODR***	Not avail	ASD / DSD	Ascending / Descending
		Play method	SMS:RPT***	Not avail	QMS:RPT	QMS:RPT***	Not avail	NON / ONE / ALL / RAN / SEL / PRG	None / Repeat one file / Repeat all files / Random / Select / Program
		Picture duration	SMS:SSD***	Not avail	QMS:SSD	QMS:SSD***	Not avail	010 ~ 600	10 - 600 seconds (5 second unit)
		Auto display content info	SMS:INF*	Not avail	QMS:INF	QMS:INF*	Not avail	0 / 1	OFF / ON
	Auto display operation guide	SMS:GUI*	Not avail	QMS:GUI	QMS:GUI*	Not avail	0 / 1	OFF / ON	
	Function button settings	Function Group	OSP:KGR***	Not avail	QSP:KGR	QSP:KGR***	Not avail	INP / MEM / ACT	INPUT / MEMORY / ACTION & MENU(SHORTCUT)
		Function Button Settings	OSP:KFN***	Not avail	QSP:KFN*	QSP:KFN***	Not avail	1 - 6 (ACTION & MENU) SIG / SSV / SUT / LNS / ECO / OSH / MLT / DZM / DID / HCO / PLE (INPUT) HM1/HM2/DV1/PC1/VD1/UD1/MV1	setup to FUNCTION KEY 1 - 6 (ACTION & MENU) SIG : Signal menu SSV : Screensaver menu SUT : Timer setup menu LNS : Network settings menu ECO : Power management settings menu OSH : AV Mute MLT : Multi display settings menu DZM : Digital zoom DID : Display ID & Display Name HCO : HDMI-CEC operation PLE : Playlist edit (INPUT) HM1 : HDMI1 HM2 : HDMI2 DV1 : DVI-D PC1 : PC(*PC[YPBPR]) VD1 : VIDEO UD1 : USB MV1 : MEMORY VIEWER (*PC input mode:PC[YPBPR])
	OSD settings	Function guide Settings	OSP:KFG*	Not avail	QSP:KFG	QSP:KFG*	Not avail	0 / 1	OFF / ON
		Menu Position	SSU:OPS*	Not avail	QSU:OPS	QSU:OPS*	Not avail	1 / 2 / 3	1:Left(Landscape) / Upper(Portrait) 2:Center 3:Right(Landscape) / Lower(Portrait)
		Menu Display Duration	SSU:MDT***	Not avail	QSU:MDT	QSU:MDT***	Not avail	005 ~ 180	Timeout time of a menu display 5 - 180 seconds (5 second unit)
		On screen display	OSP:OSD*	Not avail	QSP:OSD	QSP:OSD*	Not avail	0 / 1	OFF / ON
OSD Transparency		SSU:MTL***	Not avail	QSU:MTL	QSU:MTL***	Not avail	000 ~ 100	Transmissivity of a menu 0 ~ 100% (10% unit)	

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation		
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby				
Set up	Control settings	Display ID	-	-	QID:DID	QID:DID***	Not avail	000 ~ 100	Display ID	
		Serial ID function	SID:SID*	Not avail	QID:SID	QID:SID*	Not avail	0 / 1	OFF / ON	
		Serial Response(Normal)	SCT:RIN*	Not avail	QCT:RIN	QCT:RIN*	Not avail	0 / 1	OFF / ON	
		Serial Response(ID all)	SCT:RIA*	Not avail	QCT:RIA	QCT:RIA*	Not avail	0 / 1	OFF / ON	
	Information Timing	Serial ID Setup (Serial ID Function and Display ID)	SIF:* ***	Not avail	QIF	QIF:* ***	Not avail	0 / 1 000~100	OFF / ON Display ID	
		No Signal Warning	SIT:NSW*	Not avail	QIT:NSW	QIT:NSW*	Not avail	0 / 1	0: Off /1:On On:display sends out the no signal	
		No Signal Warning Timing	SIT:SWT**	Not avail	QIT:SWT	QIT:SWT**	Not avail	01 ~ 60	01 ~ 60 (minutes)	
		Query status :No Signal Warning Timing	-	Not avail	QST:NSW	QST:NSW*	Not avail	0 / 1	1: No Signal Warning: 0: No waring for this function. *Reply "0" when No Signal Warning is set "OFF".	
		Message of No Signal Warning (Auto) While RS-232C controls: message sent on the display automatically.	-	Not avail	-	QST:NSW*	Not avail	0 / 1	1: No Signal Warning: 0: No waring for this function.	
		No Signal Error	SIT:NSE*	Not avail	QIT:NSE	QIT:NSE*	Not avail	0 / 1	0: Off /1:On On:display sends out the no signal error..(QST:NSE*)	
		No Signal Error Timing	SIT:SET**	Not avail	QIT:SET	QIT:SET**	Not avail	01 ~ 90	01 ~ 90 (minutes)	
		Query status :No Signal Error Timing	-	Not avail	QST:NSE	QST:NSE*	Not avail	0 / 1	1: No Signal Error 0: No error for this function. *Reply "0" when No Signal Error is set "OFF".	
		Message of No Signal Error Timing (Auto) While RS-232C controls: message sent on the display automatically.	-	Not avail	-	QST:NSE*	Not avail	0 / 1	1: No Signal Error 0: No error for this function.	
		Temperature Warning	SIT:TPW*	Not avail	QIT:TPW	QIT:TPW*	Not avail	0 / 1	0: Off /1:On On:display sends out the warning temperature..(QST:TO*)	
		Query status :Temperature warning	-	Not avail	QST:TO	QST:TO*	Not avail	0 / 1	1: "HIGH TEMPERATURE-MODE". *Please check the condition. 0: "NORMAL-MODE".	
		Message of Temperature warning(Auto) While RS-232C controls: message sent on the display automatically.	-	Not avail	-	QST:TO*	Not avail	0 / 1	1: "HIGH TEMPERATURE-MODE". *Please check the condition. 0: "NORMAL-MODE".	
		Others	Recall	DDS	Not avail	-	-	-	-	Recall
			Display ID / Display name	DDS:DID	Not avail	-	-	-	-	Display ID / Display name
			Audio Mute	AOC:*	Not avail	-	-	-	0 / 1	MUTE OFF / MUTE ON
OSD Clear	VDO		Not avail	-	-	-	-	OSD Clear		
digital zoom	DZM:* * * *		Not avail	QDZ	QDZ:* * * *	Not avail	0 / 1, 1 / 2 / 3 / 4, 1 / 2 / 3 / 4 / 5, 1 / 2 / 3 / 4 / 5	OFF / ON, Enlargement factor, display position(Horizontal), display position(Vertical)		
Off Timer	ZOT:**		Not avail	-	-	-	00 ~ 90	0~90(minutes)		
USB media player	UMP:NXT		Not avail	-	-	Not avail	-	Play next content		
Skip to the next playback file	UMP:PRE		Not avail	-	-	Not avail	-	Available using USB media player		
USB media player	UMP:PRE		Not avail	-	-	Not avail	-	Play previous content		
Skip to the previous playback file	UMP:RPY		Not avail	-	-	Not avail	-	Available using USB media player		
USB media player	UMP:RPY		Not avail	-	-	Not avail	-	Play top of the content		
Playback again from top of the file	-		-	-	-	Not avail	-	Available using USB media player		
Inquiry about Signal Status of input signal	-		-	QST:SGS	QST:SGS*	Not avail	0 / 1 / 2	Signal Status information 0 : Valid signal 1 : No signal 2 : Unsupported signal		
Inquiry about Signal Frequency of input signal	-	-	QFR	QFR:H***,** V***,**	Avail	000.00 ~ 999.99, 000.00 ~ 999.99	Horizontal frequency Vertical frequency Displayed until the decimal point second place.			
Inquiry about Signal Format of input signal	-	-	QSF	QSF:*****	Avail	(MAX 20 Characters)	Signal format information			
Inquiry about HDCP status	-	-	QST:DCP	QST:DCP***	Not avail	PRT / NON / ---	Protected / None / No signal			

TYPE	Function	Control Command		Inquiry Command			Range and kind of parameter Call-back	Explanation
		Transmission Command[:Parameters]	Standby	Transmission Command[:Parameters]	Reply Command[:Parameters]	Standby		
Others	Setting Hostname	SSU:HSN*...*	Not avail	QSU:HSN	QSU:HSN*...*	Not avail	0 1 2 3 4 5 6 7 8 9 A B C D E F G H I J K L M N O P Q R S T U V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w x y z -	HOSTNAME(Max 20 Parameters)
	Auto Command Send Setting	RCM:* *	Not avail	-	-	-	0 / 1 0 / 1 (1~2 / Number of parameters is 1 to 2.)	OFF / ON --- QSS (QSS command) OFF / ON --- QSS:STSERR (QSS:STSERR)
	Inquiry about Model Name	-	-	QMN	QMN: ** * **	Avail	43 / 50 / 55 / 65 / 75 / 86 U 18	Inch size UHD model Product of 2018
	Inquiry about Model	-	-	QID	QID: **. ***.. *	Avail	43 / 50 / 55 / 65 / 75 / 86 EQ1 J / U / E / W / C	Inch size model market
	Software Version Main MCU	-	-	QRV	QRV: *.*.*.*	Avail	*Example 1.0000 EQ1	Version model
	Software Version Sub MCU	-	-	QRV:STB	QRV:STB**.*	Avail	*Example 01.00	Version
	Software Version EEPROM	-	-	QRV:EEP	QRV:EEP**.*	Avail	*Example 01.00	Version
	Software Version FRC	-	-	QRV:FRC	QRV:FRC ****	Not avail	*Example 0100	(86/75 inch only) Version
	Serial number	-	-	QSN	QSN:*****	Avail	(ASCII 9~15 / 9 to 15 figures of the ASCII characters)	(Alphanumeric character)(capital letter of the alphabet)(Blank)'-'(0x30-0x39,0x41-0x5a,0x20,0x2d)
	LAN data Cloning - Write protect	LCL:WRP*	Not Avail	QCL:WRP	QCL:WRP*	Not Avail	0 / 1	OFF / ON
	SOS History	-	-	QSS	QSS:**. **. **. **. **. **	Avail	00~FF. 00~FF. 00~FF. 00~FF. 00~FF. 00~FF	Number of times First time SOS classification 2nd SOS classification 3n time SOS classification 3n+1st SOS classification 3n+2nd SOS classification * In the 10th time, it is arranged as follows. First time SOS classification 2nd SOS classification 9th SOS classification 10th SOS classification 8th SOS classification
	Inquiry about SOS Status	-	-	QSS:STS	QSS:STS***	Avail	NON / ERR / EXT	NON : no SOS history ERR : SOS generating EXT : SOS history exists

<When [LAN control protocol] is set to [Protocol 2].>

- When the WEB control administrator privileges password has been set (Protect mode)

Connection method

1. Obtain the display's IP address and the port number (Default is 1024), and request connection to the display.
2. The display responds.

Data part	Space	Mode	Space	Random number part	Last terminal symbol
[NTCONTROL] (ASCII character string)	0x20	0x31	0x20	#zzzzzz# (ASCII code hex number)	(CR)
8bytes	1byte	1byte	1byte	8bytes	1byte

3. Hash the following data with the MD5 algorithm, and generate a 32-byte hash value.
[xxxxxx:yyyyy:zzzzzzz]

xxxxxx : WEB control administrator privileges user name
yyyyy : Above administrator privileges user password
zzzzzzz : 8-byte random number obtained in step 2

Command transmission method

Transmit in the following command format.

Transmitted data

Header	Data part	Last terminal symbol
Hash value	Control command (ASCII character string)	(CR)
32bytes	Undefined	1byte

Received data

Header	Data part	Last terminal symbol
[0]	Control command (ASCII character string)	(CR)
0x30	0x30	0x0d
1byte	Undefined	1byte

- When the WEB control administrator privileges password has not been set (Non protect mode)

Connection method

1. Obtain the display's IP address and the port number (Default is 1024), and request connection to the display.
2. The display responds.

Data part	Space	Mode	Last terminal symbol
[NTCONTROL] (ASCII character string)	0x20	0x30	(CR)
8bytes	1byte	1byte	1byte

Command transmission method

Transmit in the following command format.

Transmitted data

Header	Data part	Last terminal symbol
[0]	Control command (ASCII character string)	(CR)
0x30	0x30	0x0d
1byte	Undefined	1byte

Received data

Header	Data part	Last terminal symbol
[0]	Control command (ASCII character string)	(CR)
0x30	0x30	0x0d
1byte	Undefined	1byte

(Note)

When setting to [Protocol 1], the response in the case that sent the inquiry command is omitted the first four characters of command.

Example:

	Control Command		Inquiry Command	
	Transmission Command	Reply Command	Transmission Command	Reply Command
Protocol1	IMS:HMI	IMS	OMI	OMI:HMI
	—	—	OPW	OPW:I
Protocol2	VPC:PIC100	VPC	OPC:PIC	OPC:PIC100
	IMS:HMI	IMS	OMI	HMI
Protocol2	—	—	OPW	I
	VPC:PIC100	VPC	OPC:PIC	PIC100

For more details of the control via LAN, please obtain from the following web site.
<https://panasonic.net/cns/prodisplays/>

<「LAN control protocol」の設定が「Protocol2」の場合>

・WEB制御アドミニストレータ権限パスワード設定時（プロテクトモード）

接続方法

1. ディスプレイのIP アドレスとポート番号を取得してディスプレイへ接続を要求してください。
2. ディスプレイからの応答があります。

データ部	空白	モード	空白	乱数部	終端記号
[NTCONTROL] (ASCII文字列)	0x20	0x31	0x20	#zzzzzzz# (ASCIIコード16進数)	(CR)
8バイト	1バイト	1バイト	1バイト	8バイト	1バイト

3. MD5アルゴリズムを用いて、以下のデータから32バイトのハッシュ値を生成してください。
[xxxxxx:yyyyy:zzzzzzz]

xxxxxx : WEB 制御のアドミニストレータ権限ユーザー名
yyyyy : 上記アドミニストレータ権限ユーザーのパスワード
zzzzzzz : 手順2で取得した8バイトの乱数

コマンド送信方法

以下のコマンド形式で送信してください。

送信データ

ヘッダー	データ部	終端記号
ハッシュ値	制御コマンド (ASCII文字列)	(CR)
32バイト	不定長	1バイト

受信データ

ヘッダー	データ部	終端記号
[0]	制御コマンド (ASCII文字列)	(CR)
0x30	0x30	0x0d
1バイト	不定長	1バイト

・WEB制御アドミニストレータ権限パスワード非設定時（非プロテクトモード）

接続方法

1. ディスプレイのIP アドレスとポート番号を取得してディスプレイへ接続を要求してください。
2. ディスプレイからの応答があります。

データ部	空白	モード	終端記号
[NTCONTROL] (ASCII文字列)	0x20	0x30	(CR)
8バイト	1バイト	1バイト	1バイト

コマンド送信方法

以下のコマンド形式で送信してください。

送信データ

ヘッダー	データ部	終端記号
[0]	制御コマンド (ASCII文字列)	(CR)
0x30	0x30	0x0d
1バイト	不定長	1バイト

受信データ

ヘッダー	データ部	終端記号
[0]	制御コマンド (ASCII文字列)	(CR)
0x30	0x30	0x0d
1バイト	不定長	1バイト

(お知らせ)

「Protocol2」で、問い合わせコマンドを送信した場合の応答は、コマンドの先頭4文字を省略したものを返信します。

例:

	制御コマンド		問合せコマンド	
	送信コマンド	応答	送信コマンド	応答
Protocol1	IMS:HMI	IMS	OMI	OMI:HMI
	—	—	OPW	OPW:I
Protocol2	VPC:PIC100	VPC	OPC:PIC	OPC:PIC100
	IMS:HMI	IMS	OMI	HMI
Protocol2	—	—	OPW	I
	VPC:PIC100	VPC	OPC:PIC	PIC100

LAN経由制御に関するより詳細な説明は、以下のサポートサイトより入手してください。
業務用ディスプレイ【まかせなサイト】 <https://panasonic.biz/cns/prodisplays/>