

TYPE	Function	Control Command			Inquiry Command			Range and kind of parameter Call-back	Explanation
		Transmission Command [:Parameters]	Reception Command [:Parameters]	Standby	Transmission Command [:Parameters]	Reception Command [:Parameters]	Standby		
Others	Software Version	-	-	-	QRV	QRV: * **** * .. *** ..	Avail(*1)	*Example 1.0000 CQE1 / SQE1	Verson model < Version number conversion rule > V7.abc.d.e --> QRV:7.abcdXXXX (XXXX=model)
	Incuiry about Model	-	-		QID	QID: ** *** .. *	Avail(*1)	43 / 50 / 55 / 65 / 75 / 86 / 98 CQE1 / SQE1 W	Inch size model market
	Incuiry about Serial number	-	-	-	QSN	QSN:***** ..	Not avail	9 to 15 figures of the ASCII characters	Serial Number (Alphanumeric character)(capital letter of the alphabet)(Blank)'-(0x30-0x39,0x41-0x5a,0x20,0x2d) Reply "-----" if Display doesn't have Serial number.

(*1) Quick Standby Mode (Quick Standby) : Enabled

(*2) Supported in V.7.110.0.0 or later.