New-Generation System Cameras

LUMIX G MICRO SYSTEM

G-Series System Chart

LUMIX G VARIO 7-14mm/F4.0 ASPH. H-F007014 *1 HD Video Support *2
LUMIX G X VARIO 12-35mm/F2.8 ASPH./POWER O.I.S. H-HS12035 HD Video Support
LUMIX G X VARIO PZ 14-42mm/F3.5-5.6 ASPH./POWER O.I.S. H-PS14042 HD Video Support
LUMIX G VARIO 14-42mm/F3.5-5.6 ASPH./MEGA O.I.S. H-FS014042 HD Video Support *2
LUMIX G VARIO 14-45mm/F3.5-5.6 ASPH./MEGA O.I.S. H-FS014045 HD Video Support *2
LUMIX G VARIO HD 14-140mm/F4.0-5.8 ASPH./MEGA O.I.S. H-VS014140 HD Video Support
LUMIX G X VARIO PZ 45-175mm/F4.0-5.6 ASPH./POWER O.I.S. H-PS45175 HD Video Support
LUMIX G VARIO 45-200mm/F4.0-5.6/MEGA O.I.S. H-FS045200 HD Video Support *2
LUMIX G VARIO 100-300mm/F4.0-5.6/MEGA O.I.S. H-FS100300 HD Video Support *2
LUMIX G FISHEYE 8mm/F3.5 H-F008 *1 HD Video Support *2
LUMIX G 14mm/F2.5 ASPH. H-H014 *1 HD Video Support *2
LUMIX G 20mm/F1.7 ASPH. H-H020 *1
LUMIX G 12.5mm/F12 3D H-FT012
LEICA DG MACRO-ELMARIT 45mm/F2.8 ASPH./MEGA O.I.S. H-ES045
LEICA DG SUMMILUX 25mm/F1.4 ASPH. H-X025
OLYMPUS Lenses http://www.olympus-global.com/en/global/
SIGMA Lenses http://www.sigma-photo.co.jp/english/index.htm
COSINA Lenses http://www.cosina.co.jp/kaigai/index.html
KENKO TOKINA Lens http://www.kenkoglobal.com/

MICRO FOUR THIRDS

Wide Conversion Lens DMW-GWC1 Attachable to the H-PS14042/H-H014
Telephoto Conversion Lens DMW-GTC1 Attachable to the H-PS14042
Macro Conversion Lens DMW-GMC1 Attachable to the H-PS14042/H-H014
Fisheye Conversion Lens DMW-GFC1 Attachable to the H-PS14042/H-H014

LEICA D VARIO-ELMARIT 14-50mm/F2.8-3.5 ASPH./MEGA O.I.S. L-ES014050 *1
LEICA D VARIO-ELMAR 14-50mm/F3.8-5.6 ASPH./MEGA O.I.S. L-RS014050
LEICA D SUMMILUX 25mm/F1.4 ASPH. L-X025 *3
LEICA D VARIO-ELMAR 14-150mm/F3.5-5.6 ASPH./MEGA O.I.S. L-RS014150
OLYMPUS Lenses http://www.olympus-global.com/en/global/
SIGMA Lenses http://www.sigma-photo.co.jp/english/index.htm

FOUR THIRDS

Mount Adaptor DMW-MA1

LEICA M Mount Lenses — M Mount Adaptor DMW-MA2M
LEICA R Mount Lenses — R Mount Adaptor DMW-MA3R
Compatibility Information; http://panasonic.jp/support/global/cs/dsc/connect/mrma.html

Zoom Lever DMW-ZL1 *4

Lens Cap DMW-LFC37 DMW-LFC58 DMW-LFC46 DMW-LFC62 DMW-LFC52 DMW-LFC67
Lens Rear Cap DMW-LRC1

Body Cap DMW-BDC1

MC Protector DMW-LMCH37 DMW-LMCH58 DMW-LMC46 DMW-LMCH62 DMW-LMC52 DMW-LMCH67
PL Filter DMW-LPL37 DMW-LPL58 DMW-LPL46 DMW-LPL62 DMW-LPL52 DMW-LPL67
ND Filter DMW-LND37 DMW-LND58 DMW-LND46 DMW-LND62 DMW-LND52

Compatible with the LUMIX-GH2/H/K, G3/K/W, GX1/K/W/X
Remote Shutter DMW-RSL1

Tripod Adaptor DMW-TA1

Compatible with the LUMIX-GH2/H/K
Stereo Microphone DMW-MS1

Compatible with the LUMIX-GX1/K/W/X
Live View Finder DMW-LVF2

Compatible with the LUMIX-GH2/H/K, G3/K/W, GX1/K/W/X
External Flash DMW-FL500

Compatible with the LUMIX-GH2/H/K, G3/K/W, GX1/K/W/X
External Flash DMW-FL360

Compatible with the LUMIX-GH2/H/K, G3/K/W, GX1/K/W/X
External Flash DMW-FL220

Standard Accessories

CD-ROM

Included with the LUMIX-GH2/H/K
(PHOTOfunSTUDIO 6.0 BD Edition/ SILKYPIX® Developer Studio 3.1SE/ Super LoiLoScope Trial Version)

Included with the LUMIX-G3/K/W, GF3/C/K/W/X
(PHOTOfunSTUDIO 6.2 HD Edition/ SILKYPIX® Developer Studio 3.1SE/ Super LoiLoScope Trial Version)

Included with the LUMIX-GX1/K/W/X
(PHOTOfunSTUDIO 7.0 HD Edition/ SILKYPIX® Developer Studio 3.1SE/ LoiLoScope Trial Version)

Included with the LUMIX-GF5/C/K/W/X
(PHOTOfunSTUDIO 8.2 AE/ SILKYPIX® Developer Studio 3.1SE/ Super LoiLoScope Trial Version)

Included with the LUMIX-GX1K, GF5X, GF3X
LUMIX G X VARIO PZ 14-42mm/F3.5-5.6 ASPH./ POWER O.I.S. H-PS14042 HD Video Support

Included with the LUMIX-GH2K, G3K/W, GX1K/W, GF5K/W, GF3K/W
LUMIX G VARIO 14-42mm/F3.5-5.6 ASPH.MEGA O.I.S. H-FS014042 HD Video Support *2

Included with the LUMIX-GH2H
LUMIX G VARIO HD 14-140mm/F4.0-5.8 ASPH./MEGA O.I.S. H-VS014140 HD Video Support

Included with the LUMIX-G3W
LUMIX G VARIO 45-200mm/F4.0-5.6/MEGA O.I.S. H-FS045200 HD Video Support *2

Included with the LUMIX-GX1W, GF5C/W, GF3C/W
LUMIX G 14mm/F2.5 ASPH. H-H014 *1 HD Video Support *2

LUMIX-GH2
LUMIX-G3
LUMIX-GX1
LUMIX-GF5
LUMIX-GF3

Included with the LUMIX-GH2/H/K, G3/K/W, GF3/C/K/W/X
Stylus Pen

Battery Pack

Battery Charger

Shoulder Strap

USB Connection Cable

Included with the LUMIX-GH2/H/K, G3/K/W, GF3/C/K/W/X
AV Cable

AV Cable DMW-AVC1

Compatible with the LUMIX-GH2/H/K
Battery Pack DMW-BLC12

Compatible with the LUMIX-G3/K/W, GX1/K/W/X
Battery Pack DMW-BLD10

Compatible with the LUMIX-GF5/C/K/W/X, GF3/C/K/W/X
Battery Pack DMW-BLE9

AC Adaptor DMW-AC8 *5

Compatible with the LUMIX-GH2/H/K
DC Coupler DMW-DCC8 *5

Compatible with the LUMIX-G3/K/W, GX1/K/W/X
DC Coupler DMW-DCC9 *5

Compatible with the LUMIX-GF5/C/K/W/X, GF3/C/K/W/X
DC Coupler DMW-DCC11 *5

Leather Case DMW-CGK5 DMW-CGK11 LUMIX-GF5/C/K/W/X, GF3/C/K/W/X
(When equipped with the included or separately purchased H-PS14042/H014/H020)

Leather Case DMW-CGK6 LUMIX-GF5/C/K/W/X, GF3/C/K/W/X
(When equipped with the included or separately purchased H-FS014042/FS014045)

Leather Case DMW-CGK10 LUMIX-GF5/C/K/W/X, GF3/C/K/W/X
(When equipped with the included or separately purchased H-PS14042/H014/H020)

Leather Case DMW-CGK12 LUMIX-G3/K/W
(When equipped with the included or separately purchased H-FS014042)

Leather Case DMW-CGK13 LUMIX-GX1/K/W/X
(When equipped with the included or separately purchased H-PS14042/H014/H020)

Leather Case DMW-CGK16 LUMIX-GX1/K/W/X, GF5/C/K/W/X
(When equipped with the included or separately purchased H-PS14042/H014/H020)

Body Case DMW-CGK14 LUMIX-GX1/K/W/X

Body Case DMW-CGB3 LUMIX- GF3/C/K/W/X
DMW-CGBX1 LUMIX-GX1/K/W/X

Soft Case DMW-CG1 LUMIX-G3/K/W
(When equipped with the included or separately purchased H-FS014042/FS014045)

Soft Case DMW-CG2 LUMIX-GH2/H/K, G3/K/W
(When equipped with the included or separately purchased H-VS014140/PS45175/FS045200)

Soft Case DMW-CG3 LUMIX-GX1/K/W/X, GF5/C/K/W/X, GF3/C/K/W/X
(When equipped with the included or separately purchased H-PS14042/H014/H020)

Soft Bag DMW-CZ18
Leather Bag DMW-BAL1
Soft Bag DMW-BAG1
Soft Bag DMW-BAG2

Shoulder Strap* DMW-SSTL1
Shoulder Strap* DMW-SSTG1 DMW-SSTG2 DMW-SSTG3 DMW-SSTG5 DMW-SSTG6 DMW-SSTG7 DMW-SSTG8
Hand Strap DMW-HSTG1
Compatible with the LUMIX-GF5/C/K/W/X, GF3/C/K/W/X

*The LUMIX-GF5/C/K/W/X and GF3/C/K/W/X are available with the DMW-SSTG7 / SSTG8 only.

Personal Computer
Digital Photo Frame MW-20

SD Memory Card
SDHC Memory Card*
SDXC Memory Card*
*The LUMIX-GX1 and GF5 are compatible with UHS-I standard SDHC / SDXC Memory Cards.

HDMI mini Cable RP-CDHM15/ RP-CDHM30

Blu-ray Disc™ Player
DVD Recorder
HDTV

*1 The Auto Angle Detection (which detects when an image is taken vertically and automatically displays it vertically during playback) function cannot be used with the LUMIX-GH2 / G3 / GF3. *2 The firmware update is recommended for more comfortable HD video recording.http://panasonic.jp/support/global/cs/dsc/ (English) *3 AFS compatibility can be added with a firmware update. http://panasonic.jp/support/global/cs/dsc/index.html (English) *4 The DMW-ZL1 is compatible with the following Micro Four Thirds lenses (As of May 2012). H-F007014 / H-HS12035 / H-FS014042 / H-FS014045 / H-VS014140 / H-FS045200 / H-FS100300 *5 The AC Adaptor DMW-AC8 requires the DC coupler DMW-DCC8 / DCC9 / DCC11. The DC coupler DMW-DCC8 / DCC9 / DCC11 require the AC Adaptor DMW-AC8. •Some functions of LUMIX-GH2 / G3 / GX1 / GF5 / GF3 cannot be used when mounting the Four Thirds lenses with the Mount Adaptor DMW-MA1, the LEICA M or R lenses with the Mount Adaptor DMW-MA2M or DMW-MA3R. •Leica is a registered trademark of Leica Microsystems IR GmbH. •When a lens that does not support the Contrast AF function is mounted, operation will automatically switch to manual focus. •Confirm the operation information of compatible lenses at Customer Support http://panasonic.jp/support/global/cs/dsc (English). •For detailed information about the lenses made by SIGMA, OLYMPUS, LEICA, COSINA and KENKO TOKINA, please see each company's website. •Batteries made by other companies which have been certified by Panasonic may be used with these units, but we offer no guarantee as to the quality, performance or safety of such batteries. •Exercise care when purchasing batteries. Many fake or imitation batteries have been found among those sold at unusually low prices and those which customers cannot check for themselves before purchasing. •Please confirm the latest information about batteries on the following website. http://panasonic.jp/support/global/cs/info/battery.html (English). •The SDXC/SDHC Memory Card can be used only if the their logos are indicated on the equipment or in the operation manual. It cannot be used with equipment that supports only the SD Memory Card.