

LFV70 Backup Input

Quick

- The backup video signal needs to be in the same format as the (main) input in use for viewing.
- Upon switching to the backup input, the video and audio adjustment values for the (main) input used for viewing will be inherited. This function will start operating once a video signal is detected by both the input in use for viewing and the backup input and the "Status" item is displayed as "ACTIVE."

		Main			
		HDMI DisplayPort DIGITAL LINK DVI-D1 DVI-D2	USB	PC	Component or VIDEO
Backup	HDMI DisplayPort DIGITAL LINK DVI-D1 DVI-D2	○	x	x	x
	USB	x	-	x	x
	PC	x	x	-	x
	Component or VIDEO	x	x	x	-

- : Selectable for both Primary and Secondary.
- △: Selectable for either Primary or Secondary.
- ×: Not selectable for neither Primary nor Secondary.

* [COMPONENT] may be displayed as [RGB] depending on the settings of [Component/RGB-in select]. For more information, see the operating instructions.

Normal

- This function cannot be used when a USB input is being displayed.
- When an analogue (PC, COMPONENT or VIDEO) input is being used for viewing, you cannot set an analogue (PC, COMPONENT or VIDEO) input as a backup input.
- Analogue (PC, COMPONENT or VIDEO) inputs cannot be set simultaneously as [Primary backup input] and [Secondary backup input].

		Main			
		HDMI DisplayPort DIGITAL LINK DVI-D1 DVI-D2	USB	PC	Component or VIDEO
Backup	HDMI DisplayPort DIGITAL LINK DVI-D1 DVI-D2	○	x	○	○
	USB	○	-	○	○
	PC	○	x	-	x
	Component or VIDEO	○	x	x	-

- : Selectable for both Primary and Secondary.
- △: Selectable for either Primary or Secondary.
- ×: Not selectable for neither Primary nor Secondary.

* [COMPONENT] may be displayed as [RGB] depending on the settings of [Component/RGB-in select]. For more information, see the operating instructions.